
90mm HIGH FLOW WASTE INSTRUCTION



Maintenance:

- Remove the waste cover.
- Remove the inner filter.
- Clean with hot soapy water.

• Re-assemble in reverse order.